



Check List ***ATR/42 - 500***

Engine Start 1 Checklist

Fuel QTY: CHECKED AND ABOARD
Torque Bugs: SET
COM/NAV/ADF: SET FOR DEP
Altimeters: SET AND CHECKED
Flight Instruments: CHECKED
Trims: SET
Speed Marks/Bug: SET
Doors: CLOSED
Fuel Pumps: ON

Engine Start 2 Checklist

Fuel Pumps: ON
Beacon/Wing Light: ON
Engine 2: STARTED
Flaps: SET, INDICATING 15
Gen 2/ Ext PWR PB: CHECKED, OFF
Emer Exit Lights: ARMED
GPU/Chocks: REMOVED
White Lights: OFF
Cabin Report For Taxi: RECEIVED
ATR72 Tail Prop: ON BOARD

Taxi Checklist

Taxi Light: ON
Brakes: CHECKED
Engine 1: STARTED
Anti-Ice/WX RDR: TESTED
T/O Config: TESTED
Overboard Valve: AUTO
T/O Briefing/ADU: PERFORMED, SET
Cabin Report For T/O: RECEIVED

Before Take-off Checklist

XPRD: ALT
Flight Controls: CHECKED

COND Levers: MAX
CCAS: RECALL, T/O IN HI
External Lights: ON
Engine Start Selector: CONT RELIGHT
Anti/De-Ice: AS REQUIRED
ATR72 Bleed Valves: AS REQUIRED
Flight Instruments: CHECKED

After Take-off Checklist

Landing Gear: UP AND LOCKED
Flaps: SET, INDICATION 0
PWR Management: CLIMB
Bleed Valves: ON
Engine Start Selector: SET
5=No Smoking Signs: SET
6=Altimeters: SET

Descent Checklist

Seatbelt Sign: ON
CCAS: RECALL
Landing Elevation: SET
Speed Marks: SET

Approach Checklist

Approach Briefing: PERFORMED
Altimeters: SET
Speed Bug: SET
Torque Bugs: SET
Cabin Altitude: CHECKED
Cabin Signs: BOTH ON
Anti/De-Ice: AS REQUIRED

Final Checklist

Cabin Report For Landing: RECEIVED
Landing Gear: DOWN, 3 GREEN
PWR Management: T/O
External Lights: SET
Engine Selector: CONT RELIGHT
Flaps: SET, INDICATING 30
ATR72 TLU: LOW SPEED
ATR72 Condition Levers: AS REQUIRED

After Landing Checklist

GUSTLOCK: ENGAGED
XPDR: STANDBY
Flaps: SET, INDICATING 0
Radar Altitude: SET 0
WX Radar: STANDBY
Trims: RESET
External Lights: SET

Engine Start Selector: OFF
Anti/De-Ice: OFF
Standby Probe Heat: OFF

Parking Checklist

Parking Brake: SET
H-Mode: SET
Beacon/Wing Light: OFF
Seatbelt Sign: OFF
Emer Exit Lights: DISARMED
External Power: CHECKED, ON
H-Mode: FSO
Fuel Pumps: OFF
Fuel Used: SET 0

Securing Checklist

Oxygen Main Supply: OFF
Probe/Windshield Heating: OFF
NAV/EFIS/Radar: OFF
COM2/ADF/XPDR: OFF
Min Cabin Lights: OFF
Cabin Signs: OFF
COM1: OFF
External Lights: OFF
External Power PB: OFF
Battery Switch: OFF